


High Lifter Layout Diagram



©2012 High Lifter Pump Service

Notice: this pump will not suck or pump water out of a well. It is not suitable for flat land operation. It should only be used in hill country where the water source is above the pump. The water must first go down to the pump, then the pump moves it back up to the storage tank. For Solar Well Pumps, see the HLPS catalog.